

# Quality Accessories

Many options are available to help you develop a Champion compressor package that exactly matches your specific operating requirements.



## 1 Magnetic starter

*(included as standard on most models)*

For thermal overload protection, a starter is required for units 3 HP and up. May be mounted or unmounted.

---

## 2 Air-cooled or water-cooled aftercooler

The factory mounted, heavy duty, air-cooled aftercooler effectively reduces up to 65% of the moisture from discharged compressed air.



---

## 3 Automatic tank drain

Pneumatic drain operates from a centrifugal unloader.

---

## 4 Vibration isolators

Isolates the compressor unit from the foundation or floor. Reduces noise and protects the unit from any out-of-level floor situation that could cause vibration and damage.



---

## 5 Low oil level monitor

Low Oil Level Monitor shuts down the unit when oil levels are below an adequate level. Prevents the unit from restarting if oil levels are not at an adequate level.